



Position	Part number	Name
3	23600303301	Deck front handle
4	25285100101	Deck front panel
5	26800602501	Blade bolt
6	26800800202	Spring washer
7	26800700201	Big washer
8	504600008	Blade
9	504600009	Blade holder - Fan
10	26900203602	Bushing
11	26300195901	Grasscatcher frame
13	26801113801	Left spring of rear board
14	25316500101	Rear board
15	25316600101	Grasscatcher upper cover
17	503500106	Grasscatcher handle
19	26300136601	Rear board axle
20	26801113901	Right spring of rear board
21	25100137854	Grasscatcher bag
22	25275600901	Grass level indicator
23	23600113301	Front wheel cover
24	26800502801	Nut M8
25	26800401601	Wheel bearing
26	25400204901	Front wheel
27	26800706202	Wave washer
29	25351500101	Lower support of front axle
31	26300137401	Front wheel axle
32	25306600101	Side-discharge protecting cover
33	25286500101	Side-discharge cover board
36	26300218303	Side-discharge board
37	26801113003	Side-discharge spring
38	26200101901	Side-discharge axle
41	26900300203	Right output gear
42	26809000102	Pin
43	26800402302	Bearing
44	543000012	V-belt Z710
45	26300124401	Retainer ring
47	23050203202	Gearbox assembly
49	26300257701	Gearbox fixing plate
51	26900203103	Bearing housing
52	26900300103	Left output gear
53	25351400101	Upper support of front axle
55	26801129001	Front axle spring
57	504600057	Height adjusting rod
61	25255800102	Belt protecting cover
64	186300064	Rear wheel axle
65	26800900301	Retainer ring
66	26300107601	Washer
67	23600113401	Rear wheel cover
68	25400205001	Rear wheel
69	25229500101	Rear wheel gear ring
70	25208700105	Rear wheel inner cover
71	26300316701	Height adjusting lever
73	25400105401	Lever handle
74	23100106901	Height adjustment board
77	23600118701	Right bracket of lower handle
79	25100108505	Plastic washer
81	25236500102	Knob nut
83	23600118601	Left bracket of lower handle

Position	Part number	Name
85	504600085	Engine sheave
86	504600086	Controller
90	504600090	Dual battery connecting board
99	504600099	Flat key
104	504600104	Motor base
105	504600105	Motor
107	27600103501	Key switchbox
108	25328300101	Key
114	25205500104	Inner adjustment gear
115	504600115	Driving cable
116	25205400104	Outer adjustment gear
117	26300130101	Handle bolt
118	25236400101	Fast locking lever
119	26809004801	Pin
122	25339500101	Left pressing board
123	25339200101	Left lower cover of handle
124	25339300101	Left upper cover of handle
127	26300111901	Pressing plate
130	25233600102	Cable fixing holder
131	25339000101	Switch lower cover
132	26801126601	Button spring
133	25339400101	Safety button
134	25339100101	Switch upper cover
137	25339800101	Pulling pole left bracket
138	25339600101	Right pressing board
140	25338900301	Middle button
141	25338800301	Side button
142	25400114201	Lower handle part
146	23601025601	Driving pulling pole
150	25232600101	Mulching kit assembly
152	HECHT005040B	Battery 40V4Ah
153	HECHT005046	Charger